Contents lists available at ScienceDirect





Toxicology Reports

journal homepage: www.elsevier.com/locate/toxrep

Mainstream smoke constituents and *in vitro* toxicity comparative analysis of 3R4F and 1R6F reference cigarettes



Guy Jaccard^{*}, Donatien Tafin Djoko, Alexandra Korneliou, Regina Stabbert, Maxim Belushkin, Marco Esposito

PMI R&D, Philip Morris Products S.A., Quai Jeanrenaud 3, CH-2000, Neuchâtel, Switzerland

ARTICLEINFO	ABSTRACT
<i>Keywords:</i> Cigarettes mainstream smoke Reference cigarettes Cigarettes in vitro toxicity	A new Kentucky reference cigarette, 1R6F, has been manufactured to replace the depleting 3R4F reference cigarette. The 3R4F Kentucky reference cigarettes have been widely used as monitor or comparator cigarettes for mainstream smoke analysis and <i>in vitro</i> and <i>in vivo</i> toxicological data of cigarettes and novel tobacco products. Both reference cigarettes were analyzed in the same laboratory during the same period of time with the goal of performing a comparison of 3R4F and 1R6F. On the basis of the results obtained from aerosol chemistry and <i>in vitro</i> assays, we consider that the 1R6F reference cigarette is a suitable replacement for the 3R4F reference cigarette as a comparator/monitor cigarette. Its specific use as a comparator for novel tobacco products was checked on the basis of a comparative test with the Tobacco Heating System 2.2 as an example.

1. Introduction

The availability of reference cigarettes, prepared with a minimum of cigarette to cigarette variability and in quantities sufficient to cover a long period of time, is critical for laboratories performing smoke chemistry, in vitro testing, or in vivo analyses for cigarettes, novel tobacco products, and e-cigarettes, because reference cigarettes allow for the replication and the comparison over time of the test results obtained in other laboratories. In addition, reference cigarettes provide the most direct link between results obtained in each of the different pre-clinical trials mentioned above. Historically, the University of Kentucky provided such reference cigarettes, differing in their design and specifications, with the aim to represent various segments of the U.S. cigarette market. Lately, the Kentucky reference cigarette 3R4F has been widely used as a monitor or a comparator cigarette for mainstream smoke (MS) analyses and in vitro and in vivo toxicological assays. It has been regularly used as a monitor in collaborative tests organized for the analysis of MS constituents [1-3], or in the frame of methods development [4–9], as a comparator for analyses performed for cigarettes [4,10–15] or heated tobacco products [16-23]. It has also been used as a comparator for toxicological in vitro assays for cigarettes [24-27] or novel tobacco products and e-cigarettes [20,26,28-38] and in vivo toxicological studies [39-46]. The stock for 3R4F reference cigarette is, however, depleting. Therefore, and upon service agreement with the U.S. Food and Drug Administration, the University of Kentucky

produced 50 million cigarettes of a new Kentucky reference cigarette, 1R6F, in 2015, according to the specifications provided by the University of Kentucky (e.g., cigarette dimensions, amount of tobacco per cigarette, resistance to draw) [47]. Table 1 provides a comparison of the main cigarette design parameters of both 3R4F and 1R6F reference cigarettes.

The 1R6F Kentucky reference cigarette has been used as a monitor or a comparator cigarette until now only in a limited number of cases, such as a comparator to heated tobacco products and e-cigarettes in *in vitro* or aerosol composition studies [19,48,49], in a smoking topography study [50], or for small cigar and cigarette studies [51,52]. It has also been used as a reference in a recently published recommended method of CORESTA [53].

The goal of the present study is to compare the MS chemistry and the *in vitro* cytotoxicity mutagenicity, and genotoxicity using standard assays, of the two Kentucky reference cigarettes, 3R4F and 1R6F. Such a comparison is necessary to determine whether both reference cigarettes are interchangeable or sufficiently similar to consider previous conclusions from a range of scientific studies performed with the 3R4F reference cigarette to be equally valid considering the chemistry and toxicity of the 1R6F reference cigarette. Such a study was performed in the past for the 2R4F (predecessor of 3R4F) and 3R4F reference cigarettes, and it was suggested that they were equivalent in terms of smoke chemistry and *in vitro* and *in vivo* toxicity [39].

E-mail address: Guy.Jaccard@pmi.com (G. Jaccard).

https://doi.org/10.1016/j.toxrep.2019.02.009

Received 5 December 2018; Received in revised form 19 February 2019; Accepted 24 February 2019 Available online 25 February 2019

2214-7500/ © 2019 The Authors. Published by Elsevier B.V. This is an open access article under the CC BY-NC-ND license (http://creativecommons.org/licenses/BY-NC-ND/4.0/).

^{*} Corresponding author.

Table 1

Main cigarette design parameters of 3R4F and 1R6F Kentucky reference cigarettes.

*		
Parameter	3R4F (2006)	1R6F (2015)
Blend (%)		
Flue Cured	35.4	34
Burley	21.6	24
Maryland	1.4	-
Oriental	12.1	12
Reconstituted	29.6	20
Expanded Flue Cured		7
Expanded Burley	-	3
Cigarette Design		
Cigarette Length	84 mm	83 mm
Tobacco Rod Circumference	24.8 mm	24.6 mm
Tobacco Rod Length	57 mm	56 mm
Resistance to Draw	128 mm H2O	107
Humectants (%)		
Glycerol	2.7	1.7
Propylene glycol	-	1%
Isosweet	6.4	6.3%
Cigarette Paper		
Banded (CORESTA units)	-	9
Base (CORESTA units)	24	46
Filter Ventilation (%)	29	33
Yield data from supplier		
Puff count	9.0	7.5
TPM (mg/cig)	11.0	10.0
'Tar' (mg/cig)	9.4	8.6
Nicotine (mg/cig)	0.7	0.7
Carbon monoxide (mg/cig)	12.0	10.1

2. Methods

2.1. MS analyses

The analyses were performed under Good Laboratory Practices at Labstat International ULC. The cigarette MS was generated under ISO [54] and ISO Intense [55] analytical smoking machine conditions. The cigarettes were conditioned before analysis according to standardized conditions [56].

The list of compounds analyzed in the MS and the related methods correspond to what was applied to the 3R4F cigarette in an already published article [20]. Four replicates per analysis were performed. The list covers common lists of harmful and potentially harmful constituents (HPHC), such as the World Health Organization-39 list [57] or the Health Canada list required for the reporting of commercial brands in Canada [58].

2.2. In vitro assay analyses

The mainstream cigarette smoke total particulate matter (TPM) was generated under ISO [54] and ISO Intense [55] analytical smoking machine conditions and extracted to a stock concentration of 10 mg/mL in dimethylsulfoxide. In addition, the mainstream gas vapor phase (GVP) was generated and tested in the neutral red uptake (NRU) assay only. The Health Canada methods T501, T502, and T503 [58] were applied to the Ames assay, NRU assay, and *in vitro* micronucleus (ivMN) assay, respectively. The vehicle and positive controls in each assay and on each day of testing were within the historical control ranges used in this laboratory; therefore, the assays were considered valid.

2.3. Statistical treatment of data

The overall rationale for the comparative assessment between the 1R6F and 3R4F Kentucky reference cigarettes is based on the fundamental notion of long-term analytical variability. In the context of a single batch of reference monitor test pieces manufactured at a single point in time, the long-term analytical variability [12] represents the natural variation from analytical results obtained in different studies conducted within the same laboratory, using the same methods but at different points in time. For each constituent and specified analytical smoking machine condition, the long-term analytical variability was empirically estimated through one year of measurements conducted on the 3R4F reference cigarette at Labstat International ULC. The magnitude of the difference between 3R4F and 1R6F is evaluated constituent by constituent against the corresponding inherent precision of the analytical method over time, which is essentially driven by the longterm variability for each constituent.

For each of the constituents above the limit of quantification (LOQ) in the 3R4F monitor test piece reference data set, the critical differences for differences of means of two single point in time measurements between 3R4F and 1R6F are defined to be [59]:

Critical difference,
$$CD[\%] = 3^*\sqrt{2}^*RSD[\%]^*\sqrt{\frac{1}{n}}$$

where RSD[%] stands for the relative standard deviation in percent of the 3R4F monitor data set for the given constituent, and n = number of replicates (i.e., four replicates, as per the sample testing scheme). The performance of the 3R4F and 1R6F reference cigarettes are deemed comparable if the absolute percentage differences per constituent are within the performance boundaries expressed by the critical differences.

For endpoints where some replicates are below LOQ in the 3R4F monitor reference data set, the average yields are compared to a threshold established as 4*LOQ.

3. Results

3.1. MS chemistry

The relative percent differences for the mean individual HPHC deliveries of 1R6F cigarettes to 3R4F cigarettes were compared to the long-term 3R4F deliveries variability, according to a previously described method [12,60].

A graphical representation of the differences observed between 1R6F and 3R4F cigarettes is provided in Fig. 1.

Compounds not included in the critical difference statistical analysis, due to non-quantifiable results, include arsenic, chromium, lead, nickel, selenium, nitrobenzene, and resorcinol.

Statistically significant increases were observed for ammonia, formaldehyde, phenol, quinoline, acetamide, acrylamide, and propylene oxide under the ISO smoking regime and for propylene oxide using the ISO Intense smoking regime for 1R6F cigarettes.

Statistically significant decreases were observed for NO, NOx, NNK, NNN, and vinyl chloride under the ISO smoking regime and for 4-aminobiphenyl, acetaldehyde, acetone, butyraldehyde, MEK, propionaldehyde, NO, NOx, CO, NAB, NAT, NNK, and NNN under the ISO Intense smoking regime for 1R6F cigarettes (Fig. 2).

3.2. In vitro analyses

The 3R4F results for all *in vitro* assays and treatment conditions were within the expected (historical) range of 3R4F assay responses when the TPM was generated under intense smoking conditions. No historical ranges for the *in vitro* assays were calculated for the 3R4F MS when generated under ISO smoking conditions due to a lack of sufficient data.

3.2.1. In vitro bacterial mutagenicity

Following treatment with the 3R4F and 1R6F TPM, concentrationrelated and reproducible increases in revertants were observed in tester strains TA98, TA100, and TA1537 in the presence of S9 and in TA98 in the absence of S9 compared to solvent control when the cigarettes were smoked under ISO and ISO Intense smoking conditions. In the



Fig. 1. Graphical representation of the percentage difference between the yields of measured constituents in MS obtained under the ISO smoking regime from 1R6F and 3R4F reference cigarettes.

remaining strains and treatment conditions, no reproducible increase in revertants reproducible was observed. For these tester strains that have been proven to be responsive to TPM, the specific mutagenicity (Ames assay-specific activity slope) was determined. Then, the relative % difference in specific mutagenicity between the 1R6F and the 3R4F was compared to the 3R4F long-term variability.

This assessment showed that for the Ames assay, in any of the used strains in the presence and absence of S9 metabolic activation, the relative differences observed between the 1R6F- and 3R4F-specific mutagenicity did not exceed the calculated 3R4F long-term variability for the ISO or ISO Intense smoking regime, as shown in Table 3 and illustrated in Fig. 3.

3.2.2. In vitro cytotoxicity (NRU assay)

In the NRU assay, the TPM and GVP samples generated under ISO and ISO Intense smoking conditions induced concentration-related decreases in cell viability, and an IC_{50} value could be derived in each instance. The relative differences observed between the 1R6F and 3R4F response statistics for the NRU assay analysis did not exceed the calculated 3R4F reference item variability in any of the relevant smoking

regimes or smoke fractions, as shown in Table 4 and illustrated in Fig. 4.

3.2.3. In vitro genotoxicity (ivMN assay)

When the 1R6F and 3R4F TPMs were tested in the ivMN assay, the assay response exhibited an overall genotoxic response in each treatment condition (schedule (i), (ii), (iii)) and for each smoking regime. The schedules (i), (ii) and (iii) correspond to the schedules described in the Health Canada method T-503 [58] and correspond respectively to a short-term exposure of the cells in the absence of metabolic activation, a short-term exposure of the cells in the presence of metabolic activation and to a long-term exposure of the cells in the absence of metabolic activation. The relative difference observed between the 1R6F and 3R4F response statistics for the ivMN assay analysis did not exceed the calculated 3R4F long-term variability, with the exception of schedule (i) (short-term exposure in the absence of S9) when the TPM was generated under the ISO smoking regime, as shown in Table 5 and illustrated in Fig. 5.



CD (%) Stands for 3R4F Reference Cigarette Variability

Fig. 2. Graphical representation of the percentage difference between the yields of measured constituents in MS obtained under the ISO Intense smoking regime from 1R6F and 3R4F reference cigarettes.





CD (%) Stands for 3R4F Reference Cigarette Variability

Fig. 3. Relative % difference between Ames assay-specific activity slopes for TPM from MS of 1R6F and 3R4F cigarettes obtained under ISO (green circles) and ISO Intense (orange triangles) smoking conditions related to the long-term variability of the 3R4F (critical difference, CD).

NRU TPM and GVP Fractions: 1R6F vs. 3R4F

□ CD (%) ●% Relative Difference - ISO: 1R6F vs. 3R4F ▲% Relative Difference - ISO Intense: 1R6F vs. 3R4F





Fig. 4. Relative % difference between IC₅₀ for TPM and GVP from MS of 1R6F and 3R4F cigarettes obtained under ISO (green circles) and ISO Intense (orange triangles) smoking conditions related to the long-term variability of the 3R4F (critical difference, CD).

3.3. Use of 3R4F or 1R6F as a comparator for heated tobacco products

The 3R4F cigarette has been used as a comparator for the aerosol composition of heated tobacco products [17–20,22,26], using different lists of HPHCs, with an average reduction of about 90% (e.g., for the Tobacco Heating System (THS) 2.2) across a broad range of chemical compounds in comparison with 3R4F [16]. It was also confirmed that the average reduction in aerosol yields for THS 2.2 when compared with 3R4F was equally valid for commercial cigarettes sampled worldwide [16].

The use of 1R6F and 3R4F cigarettes as comparators for the aerosol composition of a specific heated tobacco product, THS 2.2, is provided in the Fig. 6 below.

Using the results provided in Table 1 for 3R4F and 1R6F cigarettes and the results previously published for THS 2.2 [16], there is an average reduction of 93% and 92% across the Health Canada list of HPHCs for 3R4F and 1R6F cigarettes, respectively, or 91% across the full list provided in Table 2 in comparison with both 3R4F and 1R6F cigarettes.

4. Discussion

Due to the depletion of 3R4F cigarette stock, there will soon be a need to use other reference cigarettes for comparative or monitoring purposes (e.g., for studies performed for cigarettes and novel tobacco products). The recently produced 1R6F Kentucky reference cigarettes are an obvious candidate to replace the 3R4F Kentucky reference cigarettes. We performed a study that included smoke chemistry and *in vitro* toxicological assays and used both ISO and ISO Intense smoking regimes, analogous to what was performed in the past to compare the

1R6F vs. 3R4F: iVMN

CD (%) • % Relative Difference - ISO: 1R6F vs. 3R4F • % Relative Difference - ISO Intense: 1R6F vs. 3R4F



CD (%) Stands for 3R4F Reference Cigarette Variability

Fig. 5. Relative % difference between ivMN linear regression slopes [number of MN/(mg TPM/mL)] for TPM from MS of 1R6F and 3R4F cigarettes obtained under ISO (green circles) and ISO Intense (orange triangles) smoking conditions compared to the long-term variability of the 3R4F (critical difference, CD) for each treatment schedule.

2R4F (predecessor of 3R4F) and 3R4F reference cigarettes [39].

The MS chemistry of both reference cigarettes, according to the Health Canada list of HPHCs or the wider PMI list [20] obtained under ISO and ISO Intense analytical smoking regimes, has been measured. There are some HPHCs that are either significantly higher or significantly lower in the MS of 1R6F cigarettes when compared with 3R4F cigarettes. It should be noted that with the statistical approach taken in our work [12], one expects to have 0.05*N (where N is the number of HPHC = 58), or about three occurrences of a single HPHC being significantly different when comparing 1R6F and 3R4F. Additionally, it is not expected to have the exact same profile of HPHCs in both reference cigarettes, because the cigarette design is not exactly the same, both in terms of blend (with tobaccos grown in different conditions in terms of soils, locations and environment) and cigarette construction, according to the specifications provided by the University of Kentucky (e.g., cigarette dimensions, filter properties, etc.).

Some HPHCs, such as NO, NOx, NNN, and NNK, are significantly

lower in the 1R6F cigarettes than in 3R4F cigarettes with both analytical smoking regimes. Those compounds may all be affected by the blend composition [61]; NO content in smoke is primarily determined by the nitrate content in the tobacco blend [61], and NNN and NNK are typically higher in air-cured tobaccos than in flue-cured tobaccos [62], with a tendency for a downward trend in recent years due to the introduction of new agricultural and curing practices [63,64]. The lower NNN content observed in the MS of 1R6F cigarettes is also observed in the tobacco blend, with reported values for NNN in 1R6F of 2,131 ng/g [47] or 2,294 ng/g [65] and in 3R4F of 2,636 ng/g [66]. However, this is not the case for NNK, for which the reported values are very similar, with values in 1R6F of 676 ng/g [47] and 675 ng/g [65] and in 3R4F of 679 ng/g [66]. The lower value observed for 1R6F MS NNK yields may be due to a lower transfer from tobacco to smoke of NNK, related to a lower amount of bound NNK in the blend [67,68].

Some HPHCs are significantly lower in 1R6F only for one of the two smoking regimes, such as NAB, NAT, vinyl chloride, some aldehyde



HPHC yields of Heets Regular product variant versus HPHC yields of the 3R4F and 1R6F - Stick Basis

Fig. 6. Reduction of HPHC yields for THS 2.2 in comparison with 3R4F (blue) and 1R6F (orange) cigarettes, using the ISO Intense analytical smoking machine regime.

Table 2

MS chemistry results for 3R4F and 1R6F reference cigarettes.

НРНС	3R4F ISO Mean	3R4F ISO SD	3R4F intense Mean	3R4F intense SD	1R6F ISO Mean	1R6F ISO SD	1R6F intense Mean	1R6F intense SD
Nicotine [mg/cig]	0,702	0,042	1,99 2.02	0,13	0,778	0,052	1,90 2,00	0,05
CO [mg/cig]	10,0	0,6	30,5	1,8	10,2	0,4	26,2	0,6
Ammonia [µg/cig]	9,64	1,06	32,0 34,0	1,0 0,5	12,5	0,5	29,4 35,9	0,6 1,7
Formaldehyde [µg/cig]	24,7	2,4	32,5 87,1	3,3 7,4	33,5	3,7	104	9
Acetaldehyde [µg/cig]	597	13	<i>54,1</i> 1838	<i>6,0</i> 105	532	9	<i>68,4</i> 1601	<i>3,9</i> 137
Acetone [ug/cig]	241	7	2200 749	103 44	209	7	1859 635	169 57
	50.0	,	660	24	51.0	,	520	42
Acrolein [µg/cig]	53,2	1,4	180 159	13 9	51,8	2,1	173 148	17 22
Propionaldehyde [µg/cig]	43,0	1,1	135 <i>132</i>	8 3	39,1	0,9	119 116	11 13
Crotonaldehyde [µg/cig]	9,89	0,63	59,5	4,4	10,0	0,6	55,0	5,9
Methyl Ethyl Ketone [µg/cig]	57,7	2,4	<i>42,0</i> 199	6,2 13	49,2	2,6	39,5 164	3,2 16
Butyraldehyde [µg/cig]	28,4	0,7	<i>192</i> 93,0	8 4,3	25,9	1,0	150 80,3	14 7,7
	01 5	0.2	<i>60,9</i>	5,1	08.3	14.0	51,5 252	<i>7,3</i>
now [µg/cig]	91,5	0,5	343	62	90,5	14,0	332	43
Mercury [ng/cig]	2,10	0,03	4,92 <i>4,2</i> 6	0,06 <i>0.50</i>	1,97	0,13	4,68 <i>3,89</i>	0,24 <i>0,32</i>
Cadmium [ng/cig]	24,5	2,0	93,2 105	7,4 5	26,1	2,3	76,1 88.8	1,2
Lead [ng/cig]	< LOQ	NA	< LOQ	NA	< LOQ	NA	< LOQ	NA
Chromium [ng/cig]	< LOD	NA	28,7 < LOD	<i>0,8</i> NA	< LOD	NA	28,1 < LOD	<i>0,6</i> NA
Nickel [ng/cig]	< LOD	NA	< LOQ < LOD	NA NA	< LOD	NA	< LOQ < LOD	NA NA
	. 100	N T A	< LOQ	NA		NT A	< LOQ	NA
Arsenic [ng/cig]	< TOĎ	NA	< LOQ 8,01	NA 0.56	< TOĎ	NA	< LOQ 7,57	NA 0,27
Selenium [ng/cig]	< LOD	NA	< LOD < <i>LOO</i>	NA NA	< LOD	NA	< LOD < <i>LOO</i>	NA NA
NO [µg/cig]	196	9	471	17	132	6	329	13
NOx [µg/cig]	211	9	493 524	16 17	143	6	357 369	15
Pyridine [µg/cig]	7,46	1,34	<i>555</i> 35,2	19 6,4	6,83	0,73	405 36,4	26 4,6
Quincline [ug/cig]	0.126	0.009	28,6 0.315	2,8	0.207	0.015	<i>30,4</i> 0.331	2,4 0.041
Quinonne [µg/cig]	0,130	0,009	0,313 0,389	0,033 0,028	0,207	0,015	0,331 0,427	0,009
Styrene [µg/cig]	6,54	1,17	21,7 16,1	2,4 <i>2,0</i>	4,97	0,67	20,4 1 <i>4,8</i>	2,3 <i>0,9</i>
Nitrobenzene [µg/cig]	< LOD	NA	< LOD < LOD	NA NA	< LOD	NA	< LOD < LOD	NA NA
Hydroquinone [µg/cig]	32,4	1,0	78,1	6,5	36,7	1,8	84,2	5,6
Resorcinol [µg/cig]	< LOD	NA	84,2 < LOQ	I,8 NA	< LOQ	NA	< LOQ	0,2 NA
Catechol [µg/cig]	39,5	1,5	1,57 86,9	<i>0,22</i> 5,4	43,8	1,7	<i>1,80</i> 91,9	<i>0,15</i> 5,7
Phenol [ug/cig]	6 99	0.36	<i>87,4</i> 11 1	<i>3,4</i> 0.9	0.13	0.58	91,8 11.7	<i>5,3</i>
	0,55	0,50	13,5	0,8	5,15	0,50	12,5	0,6
p-Cresol [µg/cig]	4,47	0,22	6,83 <i>8,72</i>	0,53 <i>0,38</i>	5,16	0,21	6,84 <i>7,77</i>	0,53 <i>0,41</i>
m-Cresol [µg/cig]	1,89	0,13	2,77 3,48	0,19 0,18	2,18	0,16	2,62 2,98	0,14 0.07
o-Cresol [µg/cig]	2,22	0,25	3,22	0,27	2,47	0,08	2,76	0,22
Pyrene	37,3	0,7	<i>3,94</i> 91,9	7,5	40,2	0,7	3,12 88,0	6,0
Benzo(a) anthracene [ng/cig]	12,1	0,2	79,4 28,9	7,5 2,0	13,2	0,1	68,4 27,0	10,3 1,3
Benzo(a)nyrene [ng/cig]	6 30	0.21	<i>24,2</i> 15.1	<i>2,4</i> 0.6	6 94	0 17	<i>21,4</i> 13.8	<i>3,2</i> 0.3
Denzo(a)pyrene [iig/ cig]		~, 2 1	12,9	1,3	0,77	5,17	11,4	1,7
Dibenz(a,h) anthracene [ng/cig]	< loď	NA	1,34 0,915	0,09 0,124	< lod	NA	1,19 0,892	0,20 <i>0,086</i>

(continued on next page)

Table 2 (continued)

НРНС	3R4F ISO Mean	3R4F ISO SD	3R4F intense Mean	3R4F intense SD	1R6F ISO Mean	1R6F ISO SD	1R6F intense Mean	1R6F intense SD
1,3-Butadiene [µg/cig]	37,9	3,1	100	7	39,3	3,0	102	5
			108	4			114	4
Isoprene [µg/cig]	288	18	799	61	286	24	752	36
			887	49			859	46
Acrylonitrile [µg/cig]	5,23	0,51	20,5	1,8	5,23	0,67	19,2	1,3
			19,5	1,6			18,5	1,9
Benzene [µg/cig]	33,6	2,6	88,8	6,3	33,7	2,8	82,3	4,6
			78,6	4,6			76,0	5,8
Toluene [µg/cig]	51,4	4,8	153	12	47,2	4,0	132	9
			131	5			116	9
Vinyl Chloride [ng/cig]	39,6	3,5	94,6	7,4	31,9	2,2	84,0	3,5
			95,6	9,2			109	19
Ethylene oxide [µg/cig]	6,78	0,32	19,2	1,8	5,92	0,63	17,3	0,8
			19,3	2,0			17,2	0,9
Propylene oxide [µg/cig]	297	54	1000	79	657	82	1710	138
			903	308			1692	232
1-Aminonaphthalene [ng/cig]	14,2	1,0	29,1	2,6	13,8	1,4	26,7	0,8
			17,6	0,6			17,2	0,6
2-Aminonapthalene [ng/cig]	8,77	1,11	18,1	2,3	10,7	0,8	16,2	1,3
			13,2	0,8			11,8	0,9
3-Aminobiphenyl [ng/cig]	2,27	0,09	5,44	0,23	2,33	0,28	4,49	0,39
			3,49	0,27			3,07	0,25
4-Aminobiphenyl [ng/cig]	1,54	0,12	3,91	0,29	1,48	0,05	3,13	0,04
			2,29	0,12			1,91	0,23
o-Toluidine [ng/cig]	55,9	6,9	121	1,0	59,4	4,9	109	1
			83,3	2,1			84,6	2,2
NNN [ng/cig]	131	8	337	28	100	9	230	17
			263	12			191	8
NAT [ng/cig]	136	4	334	12	110	10	259	30
			268	20			246	12
NAB [ng/cig]	13,3	0,6	31,8	1,0	11,0	1,1	24,4	2,2
			24,1	1,1			21,3	1,6
NNK [ng/cig]	113	8	295	32	84,5	6,0	192	8
			281	16			208	7
Acetamide [µg/cig]	2,70	0,18	12,2	1,9	3,99	0,42	13,2	1,0
			11,9	1,0			14,0	1,0
Acrylamide [µg/cig]	1,07	0,05	3,92	0,52	1,58	0,14	3,91	0,33
			3,99	0,39			4,49	0,34

Data in italics correspond to the results published by Forster et al [19]. NAB stands for N'-nitrosoanabasine, NAT for N'-nitrosoanatabine, NNN for N'-nitrosoana

compounds, CO, or 4-aminobiphenyl. This difference can be due either to the statistical approach mentioned above or to changes in the blend design (e.g., for NAB, NAT, or 4-aminobiphenyl) and/or cigarette design.

One compound, propylene oxide, is significantly higher in 1R6F for both analytical smoking regimes. A possible source for propylene oxide is propylene glycol used as humectant in tobacco blends [69,70]. There is a difference of 1% propylene glycol in the recipes of 1R6F and 3R4F cigarettes (1% in 1R6F; 0% in 3R4F). Gaworski et al. [70] observed an increase of propylene oxide with increasing amounts of added propylene glycol. On the basis of their results, an increase of about 850 ng/ cigarette of propylene oxide using the ISO smoking regime could be expected for an addition of 1% propylene glycol, for cigarettes differing only in their amount of added propylene glycol. We observe an increase of 360 ng/cigarette between the 1R6F and the 3R4F using ISO smoking regime, consistent with Gaworski et al. observation, noting that the design of 3R4F and 1R6F cigarettes is not the same.

Finally, some compounds are higher in 1R6F only for one of the two smoking regimes. The remarks provided above for the compounds that are higher in 3R4F cigarette MS are valid in this case, as well.

In terms of *in vitro* assay results, 1R6F and 3R4F cigarettes displayed similar *in vitro* cytotoxicity, mutagenicity, and genotoxicity under both smoking conditions, with the exception of a statistically significantly higher response of the 1R6F in the ivMN assay (schedule (i)) under ISO smoking conditions. Considering the smoke chemistry results for the 1R6F and the 3R4F, the increase in ivMN (schedule (i)) may be explained by the increase in acetamide and acrylamide in MS from the

1R6F. Although propylene oxide and formaldehyde were also increased in 1R6F MS, both constituents are mainly in the GVP, and their increase cannot explain the increase in genotoxicity of the 1R6F TPM extract. Most of the carcinogens in TPM (e.g., NNK, NNN, cadmium) were lower in 1R6F TPM or were not different between the cigarettes. Acetamide, which is classified as 2B by the International Agency for Research on Cancer (IARC) [71], is a TPM constituent and was increased by 48% under ISO smoking conditions. Acrylamide, which is classified as 2A by IARC, is also a TPM constituent and was also increased by 48% under ISO smoking conditions.

In the literature, acrylamide did not increase the mutation frequency in bacteria (e.g., TA98 and TA100). Furthermore, there is consistent evidence that activity of acrylamide in cultured mammalian cells was also seen in the absence of an exogenous metabolic activation system, implying that metabolic activation to its metabolite glycidamide might not be necessary to present its genotoxic properties [72]. All *in vivo* MN assays in mouse bone marrow cells, for example, also showed positive results without exogenous metabolic activation [72].

The toxicological profile of acetamide is less clear. In the literature, acetamide was not mutagenic in the Ames assay [71]. It was marginally positive in the induction of bone marrow micronuclei in male C57BL/6 mice in one study, but it was negative in another study at higher doses in the same species as well as in CBA male mice [71].

In summary, the physicochemical and toxicological profiles of acetamide and acrylamide are capable of explaining the increase in ivMN seen for 1R6F TPM; hence, the two smoke constituents may contribute to this genotoxic effect. However, the question arises why

Table 3

Comparison of relative % difference between mean 1R6F- and 3R4F-specific activities (revertants/mg TPM) to 3R4F long-term variability.

_				1R6F Specific Activity [revertants/mg TPM]		1R6F Specific 3R4F Specific Activity Activity [revertants/mg TPM] [revertants/mg TPM]			Mean Specific Activity Comparisons	
Smoking Regime ²	Strain and S9 Activation	Cigarette Comparison	3R4F Long Term Variability (%)	Average	Std. Dev.	Average	Std. Dev.	Observed Relative Diff. (%)	Observed Exceeds 3R4F Variability?	
ISO	TA98 (+S9)	1R6F vs. 3R4F	41.3	1551	71	1844	203	-15.9	no	
ISO	TA100 (+S9)	1R6F vs. 3R4F	64.4	651	163	722	98	-9.9	no	
ISO	TA102 (+S9)	1R6F vs. 3R4F	not determined	non-mu	ıtagenic	non-mu	itagenic			
ISO	TA1535 (+S9)	1R6F vs. 3R4F	not determined	non-mu	itagenic	non-mu	itagenic			
ISO	TA1537 (+S9)	1R6F vs. 3R4F	50.2	357	71	340	73	5.0	no	
ISO	TA98 (-S9)	1R6F vs. 3R4F	96.8	183	39	121	76	52.0	no	
ISO	TA100 (-S9)	1R6F vs. 3R4F	94.1	non-mu	non-mutagenic		non-mutagenic			
ISO	TA102 (-S9)	1R6F vs. 3R4F	not determined	non-mutagenic		non-mu	itagenic			
ISO	TA1535 (-S9)	1R6F vs. 3R4F	not determined	non-mutagenic		non-mu	itagenic			
ISO	TA1537 (-S9)	1R6F vs. 3R4F	not determined	non-mu	ıtagenic	36.3	24.3			
Intense	TA98 (+S9)	1R6F vs. 3R4F	41.3	919	50	946	68	-2.9	no	
Intense	TA100 (+S9)	1R6F vs. 3R4F	64.4	644	56	600	123	7.4	no	
Intense	TA102 (+S9)	1R6F vs. 3R4F	not determined	non-mu	itagenic	non-mu	itagenic			
Intense	TA1535 (+S9)	1R6F vs. 3R4F	not determined	non-mu	non-mutagenic		itagenic			
Intense	TA1537 (+S9)	1R6F vs. 3R4F	50.2	184	89	196	60	-6.4	no	
Intense	TA98 (-S9)	1R6F vs. 3R4F	96.8	124	45	105	14	17.9	no	
Intense	TA100 (-S9)	1R6F vs. 3R4F	94.1	non-mu	non-mutagenic		20			
Intense	TA102 (-S9)	1R6F vs. 3R4F	not determined	non-mu	non-mutagenic		non-mutagenic			
Intense	TA1535 (-S9)	1R6F vs. 3R4F	not determined	non-mu	itagenic	non-mu	itagenic			
Intense	TA1537 (-S9)	1R6F vs. 3R4F	not determined	non-mu	itagenic	non-mu	itagenic			

Note: statistical analysis not done because at least one test item was determined to be non-mutagenic overall.

The relative (%) difference is compared to the calculated 3R4F long-term variability for the assay statistic to determine if the difference exceeds the long-term variability of the Ames test method.

Table 4

Comparison of % relative difference between mean IC₅₀ (µg TPM/mL or µg TPM equivalent/mL) of 1R6F and 3R4F and the 3R4F long-term variability (significant differences of NRU assay).

					1R6F IC ₅₀ [mg/mL]		3R4F IC ₅₀ [mg/mL]		Mean IC ₅₀ Comparisons	
Smoking Regime ³	Assay	Smoke Fraction ⁴	Cigarette Comparison	3R4F Reference Item Cigarette Variability (%)	Average	Std. Dev.	Average	Std. Dev.	Observed Relative Diff. (%)	Observed Exceeds 3R4F Variability?
ISO	NRU	TPM	1R6F vs. 3R4F	37.1	68.4	10.4	69.9	13.2	-2.2	no
ISO	NRU	GVP	1R6F vs. 3R4F	33.3	160.5	39.6	136.0	17.2	18.0	no
Intense	NRU	TPM	1R6F vs. 3R4F	37.1	72.2	12.6	68.6	1.4	5.2	no
Intense	NRU	GVP	1R6F vs. 3R4F	33.3	149.5	10.0	130.2	14.6	14.9	no

Note: The relative (%) difference is compared to the calculated 3R4F long-term variability for the assay statistic to determine if the difference exceeds the long-term variability of the NRU test method.

Table 5

Comparison of relative % difference between 1R6F and 3R4F linear regression slopes [number of MN/(mg TPM/mL)] to 3R4F long-term variability for ivMN test.

						Linear Regression Slope Comparisons		
Smoking Regime ²	Schedule	Brand Comparison	3R4F Reference Item Cigarette Variability (%)	1R6F Linear Regression Slope (No. of MN/ (mg TPM/mL))	3R4F Linear Regression Slope (No. of MN/ (mg TPM/mL))	Observed Relative Diff. (%)	Observed Exceeds 3R4F Variability?	
ISO	Schedule (i)	1R6F vs. 3R4F	15.3	61.5	51.9	18.5	yes	
ISO	Schedule (ii)	1R6F vs. 3R4F	22.6	30.1	29.9	0.9	no	
ISO	Schedule (iii)	1R6F vs. 3R4F	17.7	63.9	60.9	5.0	no	
Intense	Schedule (i)	1R6F vs. 3R4F	15.3	57.6	51.4	12.2	no	
Intense	Schedule (ii)	1R6F vs. 3R4F	22.6	34.7	33.0	5.0	no	
Intense	Schedule (iii)	1R6F vs. 3R4F	17.7	56.8	63.5	-10.6	no	

Note: The relative (%) difference is compared to the calculated 3R4F long-term variability for the assay statistic to determine if the difference exceeds the long-term variability of the ivMN test method.

the results of schedule (iii) did not support the results of schedule (i). Furthermore, the 3R4F long-term variability of 15% for the ivMN (schedule (i)) seems to be very low compared with the long-term variabilities seen for the Ames assay and the NRU assay. Therefore, the increase in genotoxicity for 1R6F TPM compared with 3R4F TPM may be a chance finding. Future genotoxicity studies with 1R6F MS will show if the increase in ivMN (schedule (i)) compared with 3R4F MS is reproducible and meaningful.

When 3R4F and 1R6F cigarettes were used as comparison cigarettes to evaluate the aerosol composition of a heated tobacco product, THS 2.2, the average reduction was almost identical with both reference cigarettes. This was also true when comparing the aerosol composition of THS 2.2 with a range of commercially available cigarettes or with 3R4F reference cigarettes [16].

In conclusion, there are some slight differences in terms of smoke chemistry and *in vitro* assays for the MS of 1R6F and 3R4F reference cigarettes, obtained under ISO and ISO Intense analytical smoking machine regimes. Those differences did not, however, translate into different conclusions regarding the reduction of HPHCs in a heated tobacco product, THS 2.2.

Transparency document

The Transparency document associated with this article can be found in the online version.

References

- M. Intorp, S. Purkis, Determination of selected volatiles in cigarette mainstream smoke. The CORESTA 2008 joint experiment, Beitrage zur Tabakforschung International/ Contrib. Tob. Res. 24 (4) (2010) 174–186.
- [2] M. Intorp, S. Purkis, W. Wagstaff, Determination of tobacco specific nitrosamines in cigarette mainstream smoke: The CORESTA 2011 collaborative study, Beitrage zur Tabakforschung International/ Contrib. Tob. Res. 25 (4) (2012) 507–519.
- [3] S. Purkis, M. Intorp, Analysis of reference cigarette smoke yield data from 21 laboratories for 28 selected analytes as a guide to selection of new coresta recommended methods, Beitrage zur Tabakforschung International/ Contrib. Tob. Res. 26 (2) (2014) 57–73, https://doi.org/10.2478/cttr-2014-0010.
- [4] A.T. Vu, K.M. Taylor, M.R. Holman, Y.S. Ding, B. Hearn, C.H. Watson, Polycyclic aromatic hydrocarbons in the mainstream smoke of popular U.S. cigarettes, Chem. Res. Toxicol. 28 (8) (2015) 1616–1626, https://doi.org/10.1021/acs.chemrestox. 5b00190.
- [5] J. Jeffery, M. Carradus, K. Songin, M. Pettit, K. Pettit, C. Wright, Optimized method for determination of 16 FDA polycyclic aromatic hydrocarbons (PAHs) in mainstream cigarette smoke by gas chromatography-mass spectrometry, Chem. Cent. J. 12 (1) (2018) 27, https://doi.org/10.1186/s13065-018-0397-2 Epub 2018/03/15 PubMed PMID: 29536204.
- [6] H. Liu, S. Sun, Y. Zong, P. Li, J. Xie, Analysis of hydrogen peroxide in cigarette smoke from selected Chinese cigarette brands under conventional and intense machine smoking conditions, Eur. Food Res. Technol. 235 (6) (2012) 1107–1115, https://doi.org/10.1007/s00217-012-1840-6.
- [7] C.V. Watson, L. Valentin-Blasini, M. Damian, C.H. Watson, Method for the determination of ammonium in cigarette tobacco using ion chromatography, Regul. Toxicol. Pharmacol. 72 (2) (2015) 266–270, https://doi.org/10.1016/j.yrtph.2015. 04.019.
- [8] J. Ticha, C. Wright, Rapid detection of toxic compounds in tobacco smoke condensates using high-resolution 1H-nuclear magnetic resonance spectroscopy, Anal. Methods 8 (34) (2016) 6388–6397, https://doi.org/10.1039/c6ay00849f.
- [9] D.Y. Pazo, F. Moliere, M.M. Sampson, C.M. Reese, K.A. Agnew-Heard, M.J. Walters, et al., Mainstream smoke levels of volatile organic compounds in 50 U.S. Domestic cigarette brands smoked with the ISO and canadian intense protocols, Nicotine Tob. Res. 18 (9) (2016) 1886–1894, https://doi.org/10.1093/ntr/ntw118 Epub 2016/ 04/27 PubMed PMID: 27113015.
- [10] A. Marcilla, M.I. Beltran, A. Gómez-Siurana, D. Berenguer, I. Martínez-Castellanos, Comparison between the mainstream smoke of eleven RYO tobacco brands and the reference tobacco 3R4F, Toxicol. Rep. 1 (2014) 122–136, https://doi.org/10.1016/ j.toxrep.2014.05.004.
- [11] A. Eldridge, T.R. Betson, M.V. Gama, K. McAdam, Variation in tobacco and mainstream smoke toxicant yields from selected commercial cigarette products, Regul. Toxicol. Pharmacol. 71 (3) (2015) 409–427, https://doi.org/10.1016/j.yrtph.2015. 01.006.
- [12] M. Belushkin, G. Jaccard, A. Kondylis, Considerations for comparative tobacco product assessments based on smoke constituent yields, Regul. Toxicol. Pharmacol. 73 (1) (2015) 105–113, https://doi.org/10.1016/j.yrtph.2015.06.017.
- [13] Y. Inaba, S. Uchiyama, N. Kunugita, Spectrophotometric determination of ammonia levels in tobacco fillers of and sidestream smoke from different cigarette brands in Japan, Environ. Health Prev. Med. 23 (1) (2018) 15, https://doi.org/10.1186/

s12199-018-0704-5 Epub 2018/04/29 PubMed PMID: 29703135; PubMed Central PMCID: PMCPMC5923008.

- [14] D. Mueller, J. Schulze, H. Ackermann, D. Klingelhoefer, S. Uibel, D.A. Groneberg, Particulate matter (PM) 2.5 levels in ETS emissions of a Marlboro Red cigarette in comparison to the 3R4F reference cigarette under open- and closed-door condition, J. Occup. Med. Toxicol. 7 (2012), https://doi.org/10.1186/1745-6673-7-14.
- [15] J.J. Piadé, G. Jaccard, C. Dolka, M. Belushkin, S. Wajrock, Differences in cadmium transfer from tobacco to cigarette smoke, compared to arsenic or lead, Toxicol. Rep. 2 (2015) 12–26.
- [16] G. Jaccard, D. Tafin Djoko, O. Moennikes, C. Jeannet, A. Kondylis, M. Belushkin, Comparative assessment of HPHC yields in the Tobacco Heating System THS2.2 and commercial cigarettes, Regul. Toxicol. Pharmacol. 90 (2017) 1–8, https://doi.org/ 10.1016/j.yrtph.2017.08.006.
- [17] K. Bekki, Y. Inaba, S. Uchiyama, N. Kunugita, Comparison of chemicals in mainstream smoke in heat-not-burn tobacco and combustion cigarettes, J. UOEH 39 (3) (2017) 201–207, https://doi.org/10.7888/juoeh.39.201 Epub 2017/09/15 PubMed PMID: 28904270.
- [18] X. Li, Y. Luo, X. Jiang, H. Zhang, F. Zhu, S. Hu, et al., Chemical analysis and simulated pyrolysis of tobacco heating system 2.2 compared to conventional cigarettes, Nicotine Tob. Res. (2018), https://doi.org/10.1093/ntr/nty005 nty005-nty.
- [19] M. Forster, S. Fiebelkorn, C. Yurteri, D. Mariner, C. Liu, C. Wright, et al., Assessment of novel tobacco heating product THP1.0. Part 3: comprehensive chemical characterisation of harmful and potentially harmful aerosol emissions, Regul. Toxicol. Pharmacol. 93 (2018) 14–33, https://doi.org/10.1016/j.yrtph.2017.10.006.
- [20] J.P. Schaller, D. Keller, L. Poget, P. Pratte, E. Kaelin, D. McHugh, et al., Evaluation of the Tobacco Heating System 2.2. Part 2: chemical composition, genotoxicity, cytotoxicity, and physical properties of the aerosol, Regul. Toxicol. Pharmacol. 81 (Suppl 2) (2016) 527–s47, https://doi.org/10.1016/j.yrtph.2016.10.001 Epub 2016/10/23 PubMed PMID: 27720919.
- [21] P. Pratte, S. Cosandey, C. Goujon Ginglinger, Investigation of solid particles in the mainstream aerosol of the Tobacco Heating System THS2.2 and mainstream smoke of a 3R4F reference cigarette, Hum. Exp. Toxicol. 36 (11) (2017) 1115–1120, https://doi.org/10.1177/0960327116681653.
- [22] S. Poynton, J. Sutton, S. Goodall, J. Margham, M. Forster, K. Scott, et al., A novel hybrid tobacco product that delivers a tobacco flavour note with vapour aerosol (Part 1): product operation and preliminary aerosol chemistry assessment, Food Chem. Toxicol. (2019), https://doi.org/10.1016/j.fct.2017.05.022.
- [23] S. Uchiyama, M. Noguchi, N. Takagi, H. Hayashida, Y. Inaba, H. Ogura, et al., Simple determination of gaseous and particulate compounds generated from heated tobacco products, Chem. Res. Toxicol. 31 (7) (2018) 585–593, https://doi.org/10. 1021/acs.chemrestox.8b00024.
- [24] S. Ito, K. Ishimori, S. Ishikawa, Effects of repeated cigarette smoke extract exposure over one month on human bronchial epithelial organotypic culture, Toxicol. Rep. 5 (2018) 864–870.
- [25] H.R. Kim, J.E. Lee, M.H. Jeong, S.J. Choi, K. Lee, K.H. Chung, Comparative evaluation of the mutagenicity and genotoxicity of smoke condensate derived from Korean cigarettes, Environ. Health Toxicol. 30 (2015) e2015014, https://doi.org/ 10.5620/eht.e2015014 Epub 2016/01/23 PubMed PMID: 26796893; PubMed Central PMCID: PMCPMC4722968.
- [26] Y. Takahashi, Y. Kanemaru, T. Fukushima, K. Eguchi, S. Yoshida, J. Miller-Holt, et al., Chemical analysis and in vitro toxicological evaluation of aerosol from a novel tobacco vapor product: a comparison with cigarette smoke, Regul. Toxicol. Pharmacol. 92 (Supplement C) (2018) 94–103, https://doi.org/10.1016/j.yrtph. 2017.11.009.
- [27] H. Wang, B. Word, L. Lyn-Cook Jr., M. Yang, G. Hammons, B. Lyn-Cook, Cytotoxicity of chronic exposure to 4 cigarette smoke condensates in 2 cell lines, Int. J. Toxicol. 34 (2) (2015) 182–194, https://doi.org/10.1177/ 1091581815574349 Epub 2015/03/25 PubMed PMID: 25800266.
- [28] K. Fowler, W. Fields, V. Hargreaves, L. Reeve, B. Bombick, Development, qualification, validation and application of the Ames test using a VITROCELL[®] VC 10[®] smoke exposure system, Toxicol. Rep. 5 (2018) 542–551.
- [29] S. Antherieu, A. Garat, N. Beauval, M. Soyez, D. Allorge, G. Garcon, et al., Comparison of cellular and transcriptomic effects between electronic cigarette vapor and cigarette smoke in human bronchial epithelial cells, Toxicol. In Vitro 45 (Pt 3) (2017) 417–425, https://doi.org/10.1016/j.tiv.2016.12.015 Epub 2017/01/ 10 PubMed PMID: 28065790.
- [30] D. Azzopardi, K. Patel, T. Jaunky, S. Santopietro, O.M. Camacho, J. McAughey, et al., Electronic cigarette aerosol induces significantly less cytotoxicity than tobacco smoke, Toxicol. Mech. Methods 26 (6) (2016) 477–491, https://doi.org/10. 1080/15376516.2016.1217112.
- [31] D. Breheny, J. Adamson, D. Azzopardi, A. Baxter, E. Bishop, T. Carr, et al., A novel hybrid tobacco product that delivers a tobacco flavour note with vapour aerosol (Part 2): in vitro biological assessment and comparison with different tobaccoheating products, Food Chem. Toxicol. 106 (Pt A) (2017) 533–546, https://doi.org/ 10.1016/j.fct.2017.05.023 Epub 2017/06/10 PubMed PMID: 28595930.
- [32] L.E. Haswell, A. Baxter, A. Banerjee, I. Verrastro, J. Mushonganono, J. Adamson, et al., Reduced biological effect of e-cigarette aerosol compared to cigarette smoke evaluated in vitro using normalized nicotine dose and RNA-seq-based toxicogenomics, Sci. Rep. 7 (1) (2017), https://doi.org/10.1038/s41598-017-00852-y.
- [33] S. Ishikawa, K. Matsumura, N. Kitamura, K. Ishimori, Y. Takanami, S. Ito, Application of a direct aerosol exposure system for the assessment of biological effects of cigarette smoke and novel tobacco product vapor on human bronchial epithelial cultures, Regul. Toxicol. Pharmacol. 96 (2018) 85–93, https://doi.org/ 10.1016/j.yrtph.2018.05.004.
- [34] T. Jaunky, J. Adamson, S. Santopietro, A. Terry, D. Thorne, D. Breheny, et al., Assessment of tobacco heating product THP1.0. Part 5: in vitro dosimetric and

cytotoxic assessment, Regul. Toxicol. Pharmacol. 93 (2018) 52–61, https://doi.org/10.1016/j.yrtph.2017.09.016.

- [35] D. Malinska, J. Szymański, P. Patalas-Krawczyk, B. Michalska, A. Wojtala, M. Prill, et al., Assessment of mitochondrial function following short- and long-term exposure of human bronchial epithelial cells to total particulate matter from a candidate modified-risk tobacco product and reference cigarettes, Food Chem. Toxicol. 115 (2018) 1–12, https://doi.org/10.1016/j.fct.2018.02.013.
- [36] M. Taylor, T. Carr, O. Oke, T. Jaunky, D. Breheny, F. Lowe, et al., E-cigarette aerosols induce lower oxidative stress in vitro when compared to tobacco smoke, Toxicol. Mech. Methods 26 (6) (2016) 465–476, https://doi.org/10.1080/ 15376516.2016.1222473.
- [37] D. Thorne, S. Larard, A. Baxter, C. Meredith, M. Gaa, The comparative in vitro assessment of e-cigarette and cigarette smoke aerosols using the gammaH2AX assay and applied dose measurements, Toxicol. Lett. (2016), https://doi.org/10.1016/j. toxlet.2016.12.006 Epub 2016/12/15 PubMed PMID: 27965004.
- [38] I. Crooks, L. Neilson, K. Scott, L. Reynolds, T. Oke, M. Forster, et al., Evaluation of flavourings potentially used in a heated tobacco product: chemical analysis, in vitro mutagenicity, genotoxicity, cytotoxicity and in vitro tumour promoting activity, Food Chem. Toxicol. (2018), https://doi.org/10.1016/j.fct.2018.05.058.
- [39] E. Roemer, H. Schramke, H. Weiler, A. Buettner, S. Kausche, S. Weber, et al., Mainstream smoke chemistry and in vitro and in vivo toxicity of the reference cigarettes 3R4F and 2R4F, Beitrage zur Tabakforschung International/ Contrib. Tob. Res. 25 (1) (2012) 316–335.
- [40] E.T. Wong, U. Kogel, E. Veljkovic, F. Martin, Y. Xiang, S. Boue, et al., Evaluation of the Tobacco Heating System 2.2. Part 4: 90-day OECD 413 rat inhalation study with systems toxicology endpoints demonstrates reduced exposure effects compared with cigarette smoke, Regul. Toxicol. Pharmacol. (2019), https://doi.org/10.1016/ j.yrtph.2016.10.015.
- [41] A. Das, N. Dey, A. Ghosh, S. Das, D.J. Chattopadhyay, I.B. Chatterjee, Molecular and cellular mechanisms of cigarette smoke-induced myocardial injury: prevention by vitamin C, PLoS One 7 (9) (2012) e44151, https://doi.org/10.1371/journal.pone. 0044151 Epub 2012/09/13 PubMed PMID: 22970172; PubMed Central PMCID: PMCPMC3435405.
- [42] I.M. Olfert, E. DeVallance, H. Hoskinson, K.W. Branyan, S. Clayton, C.R. Pitzer, et al., Chronic exposure to electronic cigarettes results in impaired cardiovascular function in mice, J. Appl. Physiol. (Bethesda, Md : 1985) 124 (3) (2018) 573–582, https://doi.org/10.1152/japplphysiol.00713.2017 Epub 2017/11/04PubMed PMID: 29097631; PubMed Central PMCID: PMCPMC5899271.
- [43] C.A. Carter, M. Misra, R.R. Maronpot, Tracheal morphologic and protein alterations following short-term cigarette mainstream smoke exposure to rats, J. Toxicol. Pathol. 25 (3) (2012) 201–207, https://doi.org/10.1293/tox.25.201 Epub 2012/ 09/19PubMed PMID: 22988338; PubMed Central PMCID: PMCPMC3434335.
- [44] B.W. Phillips, W.K. Schlage, B. Titz, U. Kogel, D. Sciuscio, F. Martin, et al., A 90-day OECD TG 413 rat inhalation study with systems toxicology endpoints demonstrates reduced exposure effects of the aerosol from the carbon heated tobacco product version 1.2 (CHTP1.2) compared with cigarette smoke. I. Inhalation exposure, clinical pathology and histopathology, Food Chem. Toxicol. 116 (Pt B) (2018) 388–413, https://doi.org/10.1016/j.fct.2018.04.015 Epub 2018/04/15 PubMed PMID: 29654848.
- [45] H. Fujimoto, H. Tsuji, C. Okubo, I. Fukuda, T. Nishino, K.M. Lee, et al., Biological responses in rats exposed to mainstream smoke from a heated cigarette compared to a conventional reference cigarette, Inhal. Toxicol. 27 (4) (2015) 224–236, https:// doi.org/10.3109/08958378.2015.1027799 Epub 2015/05/15 PubMed PMID: 25969858.
- [46] S.J. Choi, S.H. Lee, S.J. Lee, M.J. Yang, K. Lee, Subchronic inhalation toxicity study of 3R4F reference cigarette smoke in rats, Mol. Cell. Toxicol. 12 (3) (2016) 313–325, https://doi.org/10.1007/s13273-016-0036-8.
- [47] Center for Tobacco Reference Products UoK, Certificate of Analysis. 1R6F Certified reference Cigarettes, 2017.
- [48] A.N. Hage, W. Krause, A. Mathues, L. Krasner, S. Kasten, J.L. Eliason, et al., Comparing the effects of electronic cigarette vapor and cigarette smoke in a novel in vivo exposure system, J. Vis. Exp. (123) (2017), https://doi.org/10.3791/55672 Epub 2017/06/02 PubMed PMID: 28570524.
- [49] R.J. Przybyla, J. Wright, R. Parthiban, S. Nazemidashtarjandi, S. Kaya, A.M. Farnoud, Electronic cigarette vapor alters the lateral structure but not tensiometric properties of calf lung surfactant, Respir. Res. 18 (1) (2017) 193, https:// doi.org/10.1186/s12931-017-0676-9.
- [50] S.M. Reilly, R. Goel, Z. Bitzer, R.J. Elias, J. Foulds, J. Muscat, et al., Effects of topography-related puff parameters on carbonyl delivery in mainstream cigarette

smoke, Chem. Res. Toxicol. 30 (7) (2017) 1463–1469, https://doi.org/10.1021/acs.chemrestox.7b00104.

- [51] R. Goel, N. Trushin, S.M. Reilly, Z. Bitzer, J. Muscat, J. Foulds, et al., A survey of nicotine yields in small cigar smoke: influence of cigar design and smoking regimens, Nicotine Tob. Res. (2017), https://doi.org/10.1093/ntr/ntx220 PubMed PMID: 29059441.
- [52] R. Goel, Z.T. Bitzer, S.M. Reilly, G. Bhangu, N. Trushin, R.J. Elias, et al., Effect of charcoal in cigarette filters on free radicals in mainstream smoke, Chem. Res. Toxicol. 31 (8) (2018) 745–751, https://doi.org/10.1021/acs.chemrestox.8b00092.
- [53] CORESTA, CRM 86. Determination of Select Carbonyls in Tobacco and Tobacco Products by UHHPLC-MS/MS, (2018).
- [54] ISO. ISO-3308, Routine Analytical Cigarette-Smoking Machine-Definitions and Standard Conditions, Ineternational Organization for Standardization, 2000.
- [55] ISO. ISO 20778, Cigarettes-Routine Analytical Cigarette Smoking Machine-definitions and Standard Conditions With an Intense Smoking Regime, (2018).
- [56] ISO. ISO 3402, Tobacco and Tobacco Products Atmosphere for Conditioning and Testing, (1999).
- [57] TobReg, WHO Study Group on Tobacco Product Regulation: Report on the Scientific Basis of Tobacco Product Regulation, WHO Technical Report Series, 2015 n. 989.
- [58] Health Canada, Canadian Ministry of Justice: Tobacco Reporting Regulations. SOR/ 200-273. Registration 2000-06-26. Part 3: Emissions From Designated Tobacco Products, (2000).
- [59] M.J. Oldham, H.J. Haussmann, W. Gomm, L.T. Rimmer, M.J. Morton, W.J. McKinney, Discriminatory power of standard toxicity assays used to evaluate ingredients added to cigarettes, Regul. Toxicol. Pharmacol. 62 (1) (2012) 49–61, https://doi.org/10.1016/j.yrtph.2011.11.018.
- [60] C. Dolka, J.J. Piadé, M. Belushkin, G. Jaccard, Menthol addition to cigarettes using breakable capsules in the filter. Impact on the mainstream smoke yields of the health Canada list constituents, Chem. Res. Toxicol. 26 (10) (2013) 1430–1443, https://doi.org/10.1021/tx400146x.
- [61] J.J. Piadé, S. Wajrock, G. Jaccard, G. Janeke, Formation of mainstream cigarette smoke constituents prioritized by the World Health Organization - yield patterns observed in market surveys, clustering and inverse correlations, Food Chem. Toxicol. 55 (2013) 329–347, https://doi.org/10.1016/j.fct.2013.01.016.
- [62] S. d'Andres, R. Boudoux, J.M. Renaud, J. Zuber, TSNA levels in the mainstream smoke of simplified blend prototypes, Beiträge zur Tabakforschung / Contrib. Tob. Res. 20 (5) (2003) 331, https://doi.org/10.2478/cttr-2013-0747.
- [63] I. Gunduz, A. Kondylis, G. Jaccard, J.M. Renaud, R. Hofer, L. Ruffieux, et al., Tobacco-specific N-nitrosamines NNN and NNK levels in cigarette brands between 2000 and 2014, Regul. Toxicol. Pharmacol. 76 (2016) 113–120, https://doi.org/10. 1016/j.yrtph.2016.01.012.
- [64] S. Appleton, R.M. Olegario, P.J. Lipowicz, TSNA levels in machine-generated mainstream cigarette smoke: 35 years of data, Regul. Toxicol. Pharmacol. 66 (2) (2013) 197–207, https://doi.org/10.1016/j.yrtph.2013.03.013.
- [65] CORESTA, CRM 72. Determination of Tobacco Specific Nitrosamines in Tobacco and Tobacco Products by LC-MS/MS, (2017).
- [66] S.H. Edwards, L.M. Rossiter, K.M. Taylor, M.R. Holman, L. Zhang, Y.S. Ding, et al., Tobacco-specific nitrosamines in the tobacco and mainstream smoke of U.S. commercial cigarettes, Chem. Res. Toxicol. 30 (2) (2017) 540–551, https://doi.org/10. 1021/acs.chemrestox.6b00268 Epub 2016/12/22 PubMed PMID: 28001416.
- [67] G. Jaccard, A. Kondylis, I. Gunduz, J. Pijnenburg, M. Belushkin, Investigation and comparison of the transfer of TSNA from tobacco to cigarette mainstream smoke and to the aerosol of a heated tobacco product, THS2.2, Regul. Toxicol. Pharmacol. 97 (2018) 103–109, https://doi.org/10.1016/j.yrtph.2018.06.011.
 [68] G. Lang, A. Vuarnoz, Matrix-bound 4-(methylnitrosamino)-1-(3-pyridyl)-1-buta-
- [68] G. Lang, A. Vuarnoz, Matrix-bound 4-(methylnitrosamino)-1-(3-pyridyl)-1-butanone in tobacco: quantification and evidence for an origin from lignin-incorporated alkaloids, J. Nat. Prod. 78 (1) (2015) 85–92, https://doi.org/10.1021/np500725a.
- [69] J. Diekmann, M. Douda, K. Rustemeier, Rapid and sensitive method for the determination of propylene oxide in cigarette mainstream smoke by gas chromatography-mass spectrometry, J. Chromatogr. Sci. 44 (1) (2006) 32–34.
- [70] C.L. Gaworski, M.J. Oldham, C.R. Coggins, Toxicological considerations on the use of propylene glycol as a humectant in cigarettes, Toxicology 269 (1) (2010) 54–66, https://doi.org/10.1016/j.tox.2010.01.006 Epub 2010/01/19 PubMed PMID: 20079797.
- [71] IARC, IARC Monographs on the Evaluation of the Carcinogenc Risk of Chemicals to Man, IARC, Lyon, 1999.
- [72] IARC, IARC Monographs on the Evaluation of the Carcinogenic Risk of Chemicals to Man, IARC, Lyon, 1994.